

HDA-RC – Wired remote control for HDA or HDV interfaces

Wired remote control for HDA or HDV interfaces. Enables direct selection of video/camera inputs and changes to settings in the OSD menus. Diameter 48mm, mounting hole 43mm, cable length 150cm. Includes plastic holder for gluing or screwing on the remote control.

Compatible with all HDA and HDV interfaces labelled with "RC" at the end of the software version.


Delivery contents




Connection

The remote control is connected instead of the external keypad. To do this, connect the 4pin female connector of the remote control connection cable to the 4pin male connector of the 20pin interface cable.

Operation – Switching between activated video inputs



Operation - OSD menu



Short = press the button briefly

Long = hold the button down for 2-3 seconds

The up arrow key ▲ corresponds to the function of the external keypad of the interface. If all inputs are activated, the sequence for a long press (2-3 seconds) is as follows:

Factory video → HDMI → V1-Left → V2-Right → V4-Reverse* → Factory video*

*HDMI only for HDV interfaces, V4-Reverse only if 'External SW' is set to 'Yes' in the V4 OSD menu.